










CAMILLE

1412_129237/1412_129238



1412_129237 1412_129238				
A		H150mm	X 4	1/1
B-L		750*610*200mm	X 1	1/1
B-R		750*610*200mm	X 1	1/1
C		1180*190*610mm	X 1	1/1
D		1100*165*25mm	X 1	1/1
E		560*570*150mm	X 2	1/1
F		1110*505*40mm	X 1	1/1
G		M8*70 mm	X 1	1/1

FR : SAV/INFORMATION /VIDEO/CONTACT

EN: AFTER-SALES SERVICE/INFORMATION/VIDEO/CONTACT

DE : REPARATUR-SERVICE UND ERSATZTEILE /INFORMATIONEN /VIDEO/KONTAKT

ES: SERVICIO POST-VENTA/INFORMACIÓN/VIDEO/CONTACTO

IT: SERVIZIO ASSISTENZA/INFORMAZIONI/VIDEO/CONTATTO

PT: SERVIÇO PÓS-VENDA/INFORMAÇÕES/VIDEO/CONTATO


PL: SERWIS TECHNICZNY/INFORMACJE/WIDEO/KONTAKT

NE: AFTER SALES SERVICE/INFORMATIE/VIDEO/CONTACT

HE: עם לתקשר/הוידאו/ מידע/ומכירות שירות לאחר


SAV.HABITATETJARDIN.COM

1




2


Slightly loosen the four bolts using Allen Key without removing the bolts completely from both Side Arms. Hook on Front Board hooks into loosen bolts, once placed tighten and secure all four bolts with Allen Key




3



4



5



6

